


# Submersible Pump HWP2 spare parts list

## From Serial No. 6459




Pos.	Part No.	Description	Pcs.
1	8232700	Volute 2", aluminium	1
2	9931522	Strainer	1
3	7632618	Lock washer M8	10
4	7632621	Screw M8x16 20 Nm	4
5	7632617	Screw M8x25 25 Nm	10
6	7401141	Q.R. coupling 1/2" BSP male	1
7	7431168	Straight fitting	2
8	7431167	Elbow fitting	2
9	7401142	Q.R. coupling 1/2" BSP female	1
10	9931508	Handle	1
11	7632622	Washer M8	4
12	9931511	Hydraulic motor	1
13	8232702	Top cover 2", aluminium	1
14	9931533	Mechanical seal assembly	1
15	9931515	O-ring f/top cover	1
16	9931517	Impeller	1
17	9931518	Shaft key	1
18	9931519	Washer	1
19	9931520	Lock nut 25 Nm	1
-	9931523	Seal kit motor w/bearings	1
-	9031552	Seal kit motor	1

# Submersible Pump HWP2 spare parts list

## From Serial No. 0100

Fig. 1



Pos.	Part No.	Description	Pcs.
2	9931508	Handle	1
6	9931509	Bolt	6
7	9931510	Lock washer	6
8	9931511	Hydraulic motor	1
9	9931533	Mechanical seal assembly	1
10	9931513	Top cover, aluminium	1
11	9931514	Bolt	4
12	9931515	O-ring f/top cover	1
13	9931516	Volute, aluminium	1
14	9931517	Impeller	1
15	9931518	Shaft key	1
16	9931519	Washer	1
17	9931520	Lock nut	1
18	9931521	Screw	4
19	9931522	Strainer	1
-	7431167	Elbow fitting	2
-	7431168	Straight fitting	2
-	7521072	Seal ring 1/2"	2
-	7401141	Q.R. coupling 1/2" BSP male	1
-	7401142	Q.R. coupling 1/2" BSP female	1
-	9931523	Seal kit motor w/bearings	1
-	9031552	Seal kit motor	1